




MORRIS

MPD-8772

MPD-9772

MPD-10772



TUMBLE DRYER

USER MANUAL

Please read this manual carefully before use this product

Content

Warning	2
Part Name	5
Installation Instruction	6
Quick start	9
The Introduction of Function and Program	10
Instructions for use	13
Service guide	13
Troubleshooting Guide	16
Specification and Circuit diagram	18

WARNING

● **Safety precautions**

Tips

This user's manual includes important information about installing, using and maintaining the machine. Please read the manual carefully so that you can use the clothes dryer correctly and its service life can be prolonged. Any failures and losses caused by non-compliance with the precautions specified in the installation and operation instructions are not covered by the warranty of the manufacturer, and the manufacturer will not assume any related responsibilities.

● **Warning matters**

- When the clothes dryer is working normally, please do not unplug or switch he power. When the machine is not used or cleaned, please unplug the plug, and do not pull the power cord. Do not use wet hands to plug the power cord.
- The clothes dryer cannot be installed in open air and humid environment. If the clothes dryer is accidentally drenched with water or water leaks into it, it shall be ventilated and dried before use.
- Wet clothes need to be dehydrated before being put into the clothes dryer in order to prevent water from dropping to electrical parts, which will damage the clothes dryer and cause danger.
- Please put the clothes dryer in a well-ventilated place to avoid other accidents.
- When the clothes dryer is working, don't use flammable sprays near it. When gas or flammable gas leaks, don't unplug the power plug or turn machine on or off.
- It is not allowed to dry clothes with flammable detergents, dry cleaning solvents, gasoline, banana oil and other chemicals.
- Don't disassemble, repair or refit the machine by yourself.
- When the clothes dryer is working, for safety, unattended children or disabled people are not allowed to use this machine.
- Do not use this clothes dryer when there is water on your hands and feet.
- Do not dry the raincoat, bicycle cover or other items containing rubber or similar elastic materials with the clothes dryer.

WARNING

● **Warning matters**

- Don't put anything hot or heavy (such as a pot with hot water) on the clothes dryer.
- Do not store cigarettes, lighters, dry ice, gasoline or other inflammable and explosive materials in the clothes dryer.
- The door of the clothes dryer can only be opened after the procedure is finished. Don't open the door forcibly before this so as to avoid scalding human skin due to overheating of the clothes dryer.

● **Warning signs of clothes dryer**

Please use this clothes dryer carefully if your clothes label indicates that it can't be dried by a clothes dryer!

● **Safety matters**

 In order to prevent damage to the personal and financial safety of you and others, please be sure to avoid the following matters:

- This product belongs to Class I electrical appliances. Please pay attention to the safety of electricity when using it!
- 1.A grounded power must be used, and the ground wire shall be directly buried in the ground, and it cannot be connected with utilities such as water pipes and gas pipelines.
 - 2.Ensure that the cross-sectional area of wires of power system can meet the requirements of the normal electrical load.
 - 3.Make sure to use the special socket separately for the machine. For the safety of you and your family, if the electricity in your home does not meet the above requirements, it is strictly prohibited to use the machine.
 - 4.In order to prevent errors in the installation and use of the socket and ensure the safety of electricity utilization, it is necessary to install the socket and connect the ground wire by the personnel with electrician knowledge.
 - 5.If it is found that the power cord is damaged, the replacement of the power cord must be carried out by professionals.




● Safety matters


6. Never connect the ground wire with the firewire or the zero wire, otherwise, the shell will be electriferous, which will easily lead to the risk of electric shock.
 7. When the clothes dryer is no longer in use, it is best to unplug the power plug from the socket to ensure safety.
 8. This machine uses alternating current. When the voltage is within 10%, this machine can be used normally.
 9. If it is necessary to use a grounded leakage (grounding protection) circuit breaker, its symbol must be  which can ensure that the plug matches the and socket match.
- For safety , reasons, please use the original parts and accessories provided by the manufacturer. If the clothes dryer can no longer be used, please cut off the power cord and destroy the door hook. Waste electrical appliances should be disposed of in the designated processing center.
 - If the material of clothes is not suitable for drying by the clothes dryer, do not use this clothes dryer for drying.
 - Don't dry unwashed clothes.
 - If there is any dust hazard (such as coal and rock powder), please do not use the clothes dryer.
 - Do not lean on the door of the machine, climb or sit on the clothes dryer.
 - If the ambient temperature around the clothes dryer is lower than 0℃, it may cause frost damage.
 - Do not let children play with packaging materials.

Part name

● Attachment specification

Steelbracket *This picture is only for the product with the rack and holder	Externaldrain pipeassembly	Plastic bracket *This picture is only for the product with the rack and holder
		

● Part name




Note: This picture is a schematic diagram, which is only for reference, the machine shall be subject to the actual product.

Installation instruction

● Install the clothes dryer


1. It is recommended to place the clothes dryer and washing machine close to each other, so that clothes can be dried after washing and dehydration.
2. To avoid blocking its fan cover due to dust accumulation, the clothes dryer shall not be put in a place with much dust.
3. Please remove all packages of the clothes dryer, and then place it on a firm and flat surface, not on a blanket or a bracket.
4. When installing, adjust the feet, make the clothes dryer horizontal. Do not fill the gap between the feet and the floor with plush carpets or wooden strips, so as not to interfere with the operation of the machine.
5. Note that the installation position shall be at least 5cm away from other furniture or walls.



● Level adjustment

By adjusting the feet, place the clothes dryer horizontally.

1. The height can be adjusted by rotating the feet.
2. You can use tools to adjust the height of the feet of the clothes dryer.
Note: Please choose a screwdriver with a diameter less than 4.5mm as the tool for adjusting the feet.



● Connection of power


1. Ensure that the power meets the requirements on the electric nameplate of clothes dryer.
2. Do not use the power strip or universal socket for secondary connection.

Installation instruction


● Accessories installation

(install them when necessary, the clothes dryer can be used normally without accessories)

(1) Installation of the external drain pipe (install it if necessary, if it is not installed, please use the water storage box)



1. Pull out the upper drain pipe downward.
2. Connect the upper drain pipe with the external drain pipe.
3. Fix the external drain pipe on the buckle




Put the external drain pipe into the sink or floor drain.
(Note that don't bend the external drain pipe)

Attention: Make sure the whole pipeline is unobstructed!

Installation instruction

• Accessories installation




Install the steel bracket according to step 2 first, and then put the plastic bracket on the steel bracket.

*This picture is only for the product with the rack and holder


Quick start

Note: Before you use this machine, please make sure that the machine has been installed correctly according to the installation instructions.


Step 1: Preparation for drying clothes



Plug in the power plug



Put in clothes




Close the door

Step 2: Start drying clothes




Step 3: End of drying clothes

When drying is finished, the clothes dryer will have a sound prompt or the word "End" will be displayed on the display screen.




Open the door,
take out the clothes




Pull the water
storage box



Pour out the
water in it



Clean the filter
screen (there are
two filter screens)




Cut off power

Note:

1. If you are using a socket with a switch, please directly press the switch to turn off power.
2. When pouring the water in the water storage box, pour it directly (without opening other parts).

The Introduction of Function and Program

● Introduction of operation panel functions



1.Start/Pause button

Press the "Start/Pause" button to start or pause the procedure.

2.Delay

Press the "Delay" button to enter the delay setting, press the "Delay" button again to select the delay time, and then press the "Start/Pause" button to start the delay. The delay time shall be selected after selecting the procedure and before pressing the "Start/Pause" button.

After the delay is started, all buttons except the "Start/Pause" button are invalid.

3.Dry Level

Press the "Dry Level" button to select the degree of dryness. Different procedures have different setting ranges for dryness. As for timing procedure, degree of dryness cannot be selected. There are 3 degrees of dryness: L1(dry) L2(drier) L3(extra dry)

4.Time-,time+

It is used to adjust the clothes drying time. Different procedures have different setting ranges of drying time. In some procedures, it can't choose drying time.

5.Child lock

In order to prevent children from misoperation during the machine operation, the child lock function can be turned on.

During the running of the procedure, press the "Time+" and "Delay" button to enter the child lock state, and the child lock indicator is on. Press the "Time+" and "Delay" button again to release the child lock state, and the child lock indicator goes out. Under the child lock state, all buttons are invalid.

6.Anti Crease

In order to avoid wrinkles when clothes are piled up after drying, the clothes dryer automatically turns on the anti crease function after the drying procedure is finished.

Press the "anti crease" button to turn on the anti crease function. The anti crease time is 180 minutes, and anti crease performed once every 10 minutes.

Introduction of other functions

 Filter screen indicator: Prompt the user to clean the filter screen.

 Water storage box indicator: Prompt the user to clean the water storage box.

- Add clothes halfway: During the drying, press the “Start/Pause” button, then the clothes dryer will pause, and you can open the door to add clothes.
- Reservation time refers to the time from the beginning of reservation to the end of drying.
- After the running procedure is finished, if there is no alarm, the End will be displayed, and the music will sound to prompt the user.
If the the user has no operation within 10minutes, it will automatically switch to the wrinkle prevention procedure.
After the wrinkle prevention is completed, the machine will automatically shut down. Under the End state, if you open the door, the machine will directly enter the Shutdown state and sound a prompt.

The Introduction of Function and Program

The following procedures are applicable to 8.0/9.0/10.0kg models:

Name	Capacity(kg)	Introduction
OFF	--	Shut down the clothes dryer
ECO	8.0/9.0/10.0kg	Dry cotton fabric
MIX	4.0/4.5/10.0kg	For the fabric blending cotton fabric and synthetic fabric
Shirts	1.0kg	Used for drying Shirts
Down Jacket	1.5kg	Used for drying down-filled coat/duvet
Delicate	3.0kg	Silk and other clothing that is not resistant to high temperatures
Hygiene	≤3.0kg	For the clothes stored for a long time, carry out sterilization treatment
Time Dry	--	Timed Procedures
Warm clothes	A little	Timing procedure/warm the clothes
Bed Linen	4.0/4.5/10.0kg	Used for heavy loads such as sheets
Baby Care	1. 0kg	Drying baby cotton fabric clothes
Air Wash	A little	Tumbles with just warm air
Towel	3.0kg	Drying Towels
Sports	A little	Timed Procedures/Breathable clothing such as sportswear
Refresh	A little	Timer procedure/Deodorization Freshness
Hair Removal	A little	Timer procedure/cleaning lint

Note:

1. The above procedures are the recommended procedures, and the users can choose appropriate procedures according to their personal habits. If the clothes are not completely dried, the users can choose the timing adjustable procedure to continue drying.
2. The timing adjustable procedure will not automatically judge the degree of wetness. If the clothes are still wet after the procedure finishes, please repeat the procedure or adjust the drying time until the clothes are dried.
3. Large fabrics such as sheets or curtains are easy to be wrapped into a ball when drying. If so, stop the clothes dryer, take fabrics out and shake them, and then put them into the clothes dryer to continue drying.
4. When drying down-filled coat, before drying, please turn the inside of the clothes to the outside.
5. The time when the machine starts is the default time. In the actual operation, the temperature and humidity of the environment, the type and weight of clothes will affect the drying time. When the machine is running, the humidity sensor intelligently senses the humidity of clothes and automatically adjusts the drying time. The display time of the corresponding LED screen will increase or decrease synchronously, which is normal.
6. The procedure with icon  indicates that the procedure is a timing procedure, and it will stop when the running time ends.

Instructions for use

● Preparations before drying clothes

Note

 After handling, please stand the machine upright for more than 2 hours before using the machine, and pick soft cloth strips to clean the inner barrel before using it for the first time.

- a) Put some cloth strips in the inner cylinder.
- b) Plug in power and press the “Power” button.
- c) Select the “Timing drying” procedure and press the “Start/Pause” button.
- d) After the procedure finishes, please clean the filter screen according to the content in the “Cleaning and maintenance”.

 During the operation of the clothes dryer, the compressor and drain pump will generate some sounds, and it is normal.

● Common knowledge and using skills of clothes dryer

1. Please dehydrate the clothes before putting them into the clothes dryer. The drier the clothes are after dehydration, the more time and electricity are saved when drying clothes.
2. Please shake the clothes, zip them up, button them up and put them in the clothes dryer; to avoid the zipper or button from making noise during drying, please turn the clothes outside over before putting them into the clothes dryer.
3. Clean the filter screen before starting the clothes dryer.
4. According to the prompt of the procedure name, select the corresponding drying procedure according to the material type and label information of the clothes.
5. In order to get the ideal drying effect, please classify the clothes, and don't dry the clothes with different thickness or different degrees of dryness or wetness at the same time as far as possible.
6. When drying a small amount of clothes, it is recommended to use the timing adjustable procedure.
7. When drying sheets, curtains and other large-sized fabrics, if in the drying process, the fabrics are lumped, the operation can be suspended, and drying can continue after shaking.
8. For the clothes that need to be dried by the clothes dryer, it is recommended to use fabric softener when washing.
9. Some heavy clothes (jeans, big towels, etc.) are difficult to be dried locally because of the material characteristics; if you find that the drying is still incomplete after the end of the procedure, it is recommended to use the “Timing drying” procedure to adjust the drying time.


Service guide

● Cleaning and maintenance

a、 Empty the water storage box

Steps:

- (1) Hold it with both hands and pull the water storage box;
- (2) Pour out the water in the water storage box;
- (3) Set the water storage box to its original position.



Warning

- Please clean the water storage box after each use. If the water storage box is full of water during the drying process, the procedure will pause, and the water box light on the display will be on. You shall empty the water storage box, then press the “Start/ Pause” button to restart the clothes dryer.
- Condensed water is not drinkable!
- Do not use the clothes dryer without the water storage box!


b、 Clean the filter screen assembly

The machine has one or two filter screens, it depends on the model. The filter screen shall be cleaned after each use.

Cleaning of barrel filter screen:

Open the door→take out the barrel filter screen→open the barrel filter screen→clean the barrel filter screen→put the barrel filter screen back to the original position.

Barrel filter screen:



Cleaning steps:

- (1) Clean the filter screen and vent, remove fluff accumulated on the filter screen and vent, then rinse in running water or clean with a soft brush:
- (2) Ensure that the filter screen is completely dried before reinstalling it.

Service guide

● Cleaning and maintenance

Warning

- Too much fluff on the filter screen will block the air circulation, which will delay dryin time and increase energy consumption!
- Do not use the clothes dryer when there is no filter screen!
- Clean the filter screen after each use!
- Clean the heat exchanger
- According to the need, it is recommended to clean the heat exchanger once every month.

Cleaning step:

- (1) Open the lower filter screen baffle in the lower left corner of the machine;
- (2) Turn the knob and take out the lower filter screen;
- (3) Clean the exchanger with a soft brush:
- (4) After cleaning, return the lower filter screen, knob and baffle to their original positions.

Note:



1. Do not press it hard when cleaning the heat exchanger, otherwise it will damage the heat exchanger.
2. Disconnect the power before cleaning!
3. Clean the drum clothes dryer

Warning

- Disconnect the power before cleaning!
- Please wear gloves when cleaning.
- When cleaning the surface or other parts of the clothes dryer, use a wet cloth soaked with clean water, otherwise the plastic surface or other parts may be damaged.
- Do not rinse the clothes dryer directly with tap water hose or high-pressure water gun.

Cleaning steps:

- Prepare a wet cloth soaked in clean water.
- Clean the door, especially the internal windows.
- Clean the sealing ring around the front support.
- Clean the humidity sensor of the drum.
- Clean fluff in the air duct.
- Before starting the machine, dry it with a soft cloth.



Troubleshooting Guide

● Cleaning and maintenance

Note: The humidity sensor is located inside the drum of the clothes dryer and is under the collection port.

Do not clean drum with corrosive detergent, or don't scratch the humidity sensor.

● Alarm prompt

Alarm prompt	Alarm reason	Solution
OE	The water storage box is full or the drain pump is abnormal	If the fault is not solved after emptying the water storage box, please call the national service hotline
dE	The door is not closed or the door is not closed completely	If the fault has not been solved after closing the door again, please call the national service hotline
LE	The filter screen is not cleaned, or motor is abnormal	If the fault is not solved after cleaning the filter screen, please call the national service hotline
HE	The compressor is abnormal	Please turn off power and call our service number.
tE1	Temperature of front air duct is abnormal	
tE2	The condenser temperature is abnormal	
SE	The humidity sensor is abnormal	

Remarks:

When  appears during the machine operation, please check whether the water storage box is full. If so, please empty it and restart the machine. If not, please start the machine directly.

When  appears during the running machine, please check whether the barrel filter screen and the lower filter screen are full. If the filter screen is full of fluff, please clear it and restart the machine; if not, please start the machine directly.

Troubleshooting Guide

● Fault phenomena and treatment methods

 Only authorized professional service technicians can repair the clothes dryer!

Before calling the hotline, please confirm whether you can handle the trouble by yourself or the machine is used correctly, the technicians will give you advice when it is within the warranty period.


Problem	Solution
The computer plane does not display any content	Check whether the power or power plug is normal; check whether the power switch is turned on.
The clothes dryer is not started	Confirm whether the door of the clothes dryer is closed. Confirm whether the procedure is selected and the "Start /Pause" button is pressed.
The door opens automatically	Press and hold the door handle, so that the door lock can be locked in the corresponding position. Check whether the clothes are excessive.
The drying standard is not reached or the drying time is too long.	Clean the barrel filter screen and lower filter screen; use a more appropriate drying procedure; ensure that the fan cover is unobstructed.

 If you can't eliminate the fault, please:

1. Turn off power of the clothes dryer.
2. Call our service number.

Specification

Model	MPD-8772	MPD-9772	MPD-10772
Maximum drying capacity (kg)	8.0	9.0	10.0
Rated power (W)	650	650	700
Product size (w*d*h) (mm)	595*615*850	595*615*850	595*670*850
Refrigerant	R290	R290	R290
Filling amount of refrigerant (g)	130	130	110



⚠ NOTE:

1. The energy efficiency rating was tested under “ECO 40-60” procedure.
2. Scan the QR code shown on the energy label for further product information.
3. When the washing machine gives error codes, make sure you contact our after sales team to repair. We shall not be responsible for any issue caused by unauthorized repair.
4. In case you need to order the accessories, we can send out within 15 working days after the request.
5. For the purpose of improving the performance of the whole washing machine, the appearance and specifications shall be changed without additional notice.

DECLARATION OF CONFORMITY

Herewith, we state that this product, complies with the requirements of below directives:

EMC-Directive: 14 / 30 / EU

Low Voltage Directive: 14/ 35 / EU

ErP Directive 09 / 125 / EC

CE Marking: 93 / 68 / EEC

RoHS Directive: 11 / 65 / EU & Delegated Directive (EU) 15 / 863

The detailed declaration of conformity can be found at www.morris.gr



Kalliopi Karyda & Co LP.

87A, 17is Noemvriou str.
55535, Pylea, Greece
Tel. +30 2316 006600
www.morris.gr