



# Einhell

# CLASSIC



Cordless Jig Saw

**TC-JS 18/70 Li (1x2,5Ah)**

**Item No.: 4321280**

Ident No.: 21014

Bar Code: 4006825679519

The Einhell TC-JS 18/70 Li (1x 2.5 Ah) cordless jigsaw provides many versatile applications. As a member of the Power X-Change family, it provides flexibility for various jobs. With an idle speed of 2,700 rpm, it enables precise cuts up to 70 mm deep in wood and 8 mm deep in steel. The switchable pendulum stroke always ensures fast cutting progress. The T-shaft sawblade holder enables quick and tool-free blade changes. The dust blow-off function and the dust extraction connection ensure the best visibility when working. Supplied with 1x 2.5 Ah Power X-Change battery, 1x charger, 1x jigsaw blade for wood, 1x suction adapter and 1x hexagon key.

## Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Very smooth operation for precise cutting
- Speed electronics to adapt to the material
- Pendulum stroke function for fast sawing progress
- Tool-free saw blade change
- Dust blow-off function for the best view
- Plastic shoe cover protects delicate workpieces
- Incl. chip breaker for tear-free cutting
- Incl. dust extraction for a clean workplace
- Hexagon key for cutting angle adjustment up to 45°
- Incl. 1 x 2.5 Ah Power X-Change battery and charger




## Technical Data

- |                                   |                          |
|-----------------------------------|--------------------------|
| - Accumulator                     | 18 V   2500 mAh   Li-Ion |
| - Charging time                   | 50min                    |
| - Mains supply of battery charger | 200-250 V   50-60 Hz     |
| - No-load speed ( idle speed )    | 2700 min <sup>-1</sup>   |
| - Stroke height                   | 20 mm                    |
| - Cutting depth in wood           | 70 mm                    |
| - Cutting depth in plastic        | 10 mm                    |
| - Cutting depth in steel          | 8 mm                     |
| - Max. bevel cuts                 | 45 °                     |
| - Toolless saw blade change       | yes                      |
| - Number of accumulators          | 1 Pieces                 |



## Logistic Data

- |                                      |                    |
|--------------------------------------|--------------------|
| - Product weight                     | 2.12 kg            |
| - Gross weight single packaging      | 3.11 kg            |
| - Dimensions single packaging        | 243 x 175 x 243 mm |
| - Pieces per export carton           | 4 Pieces           |
| - Gross weight export carton         | 14 kg              |
| - Container quantity (20"/40"/40"HC) | 2472   5124   6000 |



## Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery  
Item No.: 4511502  
Bar Code: 4006825644210



4,0 Ah Power X-Change Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit  
Item No.: 4512108  
Bar Code: 4006825652376  
Einhell Accessory



18V 3,0 Ah Power-X-Change 1 Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



PXC Battery Mounting Gadget PXC-Battery Accessory  
Item No.: 4514155  
Bar Code: 4006825658774  
Einhell Accessory



Power X-Caravan Charger 3A Charger  
Item No.: 4512136  
Bar Code: 4006825664010  
Einhell Accessory



Power X-Boostcharger 8A Charger  
Item No.: 4512155  
Bar Code: 4006825670554  
Einhell Accessory



PXC Battery Protector PXC-Battery Accessory  
Item No.: 4140151  
Bar Code: 4006825670844  
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



18V 4,0Ah SEALED PXC Plus A1 Battery  
Item No.: 4511627  
Bar Code: 4006825673227  
Einhell Accessory



18V 3Ah PXC Plus Twinpack Battery  
Item No.: 4511631  
Bar Code: 4006825673692  
Einhell Accessory



2,0 Ah Power X-Change Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1 PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



Power X-Fastcharger 4A Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory




2x18V 4,0Ah PXC-Twinpack CB A1 Battery  
Item No.: 4511489  
Bar Code: 4006825638578



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit  
Item No.: 4512143  
Bar Code: 4006825667653  
Einhell Accessory



5,2 Ah Power X-Change Plus Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



Stich-Sägeblatt Box 10-tlg. T Stichsägen-Zubehör  
Item No.: 49617350  
Bar Code: 4009316173503  
Einhell Accessory



St-Sägebl.Set 4tg Ho/Met Akku Stichsägen-Zubehör  
Item No.: 49625427  
Bar Code: 4009316254271  
Einhell Accessory



18V 4Ah PXC Plus Twinpack Battery  
Item No.: 4511629  
Bar Code: 4006825673685  
Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



18V Battery Charger 3,0A - PXC Charger  
Item No.: 4514095  
Bar Code: 4006825655292  
Einhell Accessory



5,2 Ah PXC Starter-Kit  
 PXC-Starter-Kit  
 Item No.: 4512147  
 Bar Code: 4006825675153  
 Einhell Accessory




18V 3,0Ah SEALED PXC Plus A1  
 Battery  
 Item No.: 4511618  
 Bar Code: 4006825672794  
 Einhell Accessory



3,0 Ah Power X-Change Plus  
 Battery  
 Item No.: 4511501  
 Bar Code: 4006825644197  
 Einhell Accessory

## Battery-Running-Times

One Battery for All	 sawing <sup>1</sup> (m)
1.5 Ah	7
2.0 Ah	9.5
2.5 Ah	11
3.0 Ah	14
4.0 Ah	20
5.2 Ah	30
6.0 Ah	32
8.0 Ah	40

**Test setup:**

1) wood - chipboard 19 mm